

Guide of Invt PV Pump IOT Monitoring System

1, wiring





Diagram of connecting the GPRS module to the inverter


2,IOT system

1),Landing site :<http://iot.invt.com:12000>


2),Choose the language



3),Key the account name and the password
(You need not to register the account name that the salesman will sent to you in advance)



4),Add devices



5) Down load the phone app and land the mobile web page

Sweep the QR-code to land the mobile web page



Sweep the QR-code to download Android APP



If your phone is iPhone you can download the IOS APP on the App Store though search the “invt pump”.

